

气动升降桌使用说明书

sit atand Desk Instruction Manual

使用产品前请仔细阅读并妥善保管

Please read and keep it safe before using the product

01.产品功能说明 ----------1
Product Function Description

02.产品清单及使用说明 ----------2
Product List and Instructions for Use

03.注意事项 ----------3
Matters needing attention

04.产品保修卡 ----------4
Warranty Card

01 - 产品功能说明
Product function description



① 升降桌桌面
The desktop of standing desk

② 调节按钮
Adjustment Button

③ 支撑骨架
Supporting skeleton

④ 升降桌底座
The base of standing desk

02 - 产品清单及使用说明
Product List and Instruction of Installation

1、产品清单
Product List

■ 内含：电动升降台、合格证、说明书。
Inclusion: Suitable for electric lifting platform, qualification certificate and instruction.

2、安装说明
Instruction of installation







① 将产品放置在使用桌面上。
Take the product out of the box and place it horizontally on the desktop.

② 接上电源。
Connect the power supply.

③ 底座尾部有倾斜支撑架，可选择是否倾斜
Use the lift button to raise to the appropriate height and start using.

④ 使用升降按钮升降至合适的高度，开始使用。
Use the lift button to raise to the appropriate height and start using.

03 - 注意事项
Matters needing attention

警告：有夹手的风险，使用时请小心。
WARING: Risk of finger injury-pinching hazard.Use caution when lowering desk.

警告：如果本产品不能正常工作，摔坏、浸水，请不要操作本产品。如有任何问题，请于办公时间内与客户服务部联络。如有需要，我们的客户服务团队将提供一个替代品。
WARING: Never operate this product if it is not working properly, if it has been dropped or damaged, or dropprd into water. Contact our customer service department during business hours to report any issues. Our customer service team will provide a replacement if necessary.

警告：为了减少火灾、电击或人身伤害的风险，请在室内使用，不要放置在潮湿的地方。
WARING: To reduce risk of fire,electric shock or personal injury,use only inds and do not install in a wet or damp location.

警告：保证显示器或笔记本电脑完全放在工作台上。
WARING: Keep monitor and laptop base fully on the worksurface.Allowing any part of stand to hang off the edge may result in property damage and or personal injury.

警告：不要将手放在支撑杆上或靠近支撑杆，工作台任何部位的悬空都有可能会造成不必要的财产损失或人身伤害,避免在升降过程中夹手。
WARING: Do not place hands on or near support bars.Pinch points are created during lifting and lowering the worksurface. Failure to follow these instructions may result in serious personal injury.

警告： 本产品虽做了一定保护,但是浸水还是有可能发生故障。
CAUTION: Beverages such as water or coffee could cause product failure if spoilled.

04 - 产品保修卡
Product Warranty Card

尊敬的用户:
Dear users

1、升降台提供气动款三年质保，电动款五年质保服务；自签收之日起7天内商品完好不影响二次销售的支持7天无理由退换货；支持15天内换货，质量问题商家承担，非质量问题客户承担。
We will provide three-year warranty service for gas spring standing desk converterand five-year warranty service for electric standing desk converter;The goods are in good condition within 7 days from the date of receipt support for secondary sales for 7 days without reason;Support to change the goods within 15 days, and the quality problem shall be borne by the merchants, while the non-quality problem shall be borne by the customers.

2、在保修期内，产品凡属于性能故障，均免费维修。
During the warranty period, the products are free of charge if they are performance faults.

3、下列情况不属于免费维修范围，但可以实行收费修理：
The following conditions are not covered by the free repair, but can be repaired at a charge:

（1）产品超出保修期。
Product is out of warranty.

（2）无法提供产品保修卡及购桌发票的。
Unable to provide product warranty card and purchase desk invoice.

（3）人为因素或用户使用不当造成的损坏，如磕碰、敲击、腐蚀性物体或液体接触锁体等。
Human factors or damage caused by the improper use of the user, such as bumps, knocks, corrosive objects or liquid contact locks, etc.

（4）因不可抗拒力造成损坏的，如雷击、火灾、洪水、地震、台风等。
Damage caused by force majeure, such as lighting strikes, fires, floods, earthquakes, typhoons, etc.

保修凭证

Warranty Certificate

产品型号 Product Model		产品序列号 Product Serial Number	
客户名称 Client's Name		联系电话 Contact Number	
购买日期 Date of Purchase		收货日期 Receipt Date	
联系地址 Contact Address			

序号 Serial Number	型号/序列号 Model/Serial Number	现象及解决方法 Phenomenon and Solution	维修签字 Repair Signature	日期 Date

■ 请用户妥善保管维修卡，遗失不补，涂改无效。

Please keep the maintenance card properly, if it is lost, it will not be replenished. And invalid change.